



6. Passenger Lift

Otis Elevator Company Pty Ltd

Lifts 1 & 2 (Low Rise Tower – 227 Toorak Road) : B3 to L9

Lifts 3 to 5 (High Rise Tower – 229 Toorak Road) : B3 to L24

Emergency Procedure:

Please use telephone call panel in cases of emergency.

Fixtures on the panel include alarm push button which sounds an audible alarm to warn those in the lift need assistance.

Intercom- If the button is activated there is a vocal connection between the lift car and the intervention service. The receiver will assist in notifying the intervention service the installation and address of ILK South Yarra (227 or 229 Toorak Road, South Yarra 3121).

Lift Fault:

Please contact Owners Corporation if lift fault occurs.

Lift Operation:

Once in the lift car present access tag in front of tag reader to gain access to your floor level (push button on appropriate floor).

Note: Other floor levels (except L3 gym, L3 pool and L9 communal areas) will be restricted.

Lift can be operated on the lift landing and lift car by push buttons. When your instruction has been received a light will illuminate the signal given. The lift panel will also indicate direction of travel and its current floor location. Emergency alarm button and door open button, door close button are also fitted on the operation panel.

Internal Lift Dimensions:

| Low Rise Tower (Lifts 1 & 2) | | High Rise Tower (Lifts 3 to 5) | |
|---------------------------------|------|-----------------------------------|------|
| Door Width | 1.1m | Door Width | 1.1m |
| Car internal height | 2.4m | Car internal height | 2.4m |
| Car internal width | 1.4m | Car internal width | 1.4m |
| Car internal depth | 2.0m | Car internal depth | 2.0m |

PLEASE DO NOT USE LIFTS IN CASES OF FIRE